


MANHOLE ADJUSTMENT SEQUENCE

(For details not shown, refer to Std. Dwg. GP338 & GP352)



General Notes:

1. Cover manhole with building paper. Lay asphalt base and wearing courses.
2. Sawcut diamond excavation around manhole, 12" min from manhole frame.
3. Raise manhole frame and cover to finish grade by installing concrete rings and leveling mortar.
4. Backfill with 1/2" dense grade level 2 mix asphalt (compacted in 3" lifts) to finish grade.
5. Asphalt class may match existing street asphalt with permission of City Engineer.

The selection and use of this standard drawing, while designed in accordance with generally accepted engineering principles and practices, is the sole responsibility of the user.

Designed By: STAFF
 Drawn By: KJD
 Checked By: MPT
 Approved: JMC

No.	Date	Revisions	App. By



CITY OF GRANTS PASS
 101 Northwest 'A' Street
 Grants Pass, OR 97526
 (541) 450-6060 ph (541) 476-9218 fax

MANHOLE ADJUSTMENT SEQUENCE

2018

DWG. NO. GP312